



## Rear Spoiler Installation Instructions

Thank you for your purchase of a Texas D.A.R. Enterprises, Inc. product! We are confident that you will appreciate the fine quality and craftsmanship of your selection. Texas D.A.R. stands proudly behind each and every product we manufacture and guarantee our work with a 3 Year/36K Mile Warranty. For details please refer to our website @ [www.texasdar.com/warranty.asp](http://www.texasdar.com/warranty.asp) or call customer service at 1-800-265-9917. We appreciate your business and look forward to your business in the year ahead.

**PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE ANY INSTALLATION OR PREP-WORK BEGINS**

### STEP 1.

After opening and inspecting your CarData rear spoiler you can begin the installation. Notice that the LED light and the pedestal gaskets come pre-installed from the factory (pre-painted spoilers only), which will shave some time off the installation.

### STEP 2.

Start out by turning over the spoiler and setting it on a soft surface, to prevent any scratches. Place the plastic locator T-strips into the mounting holes on spoiler and LED brake light hole. *TIP: A small piece of masking tape is helpful in holding the T-strips in position.*

### STEP 3.

Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a "perfect" alignment.

### STEP 4.

Using masking tape, secure locator T-strips to the decklid of the vehicle. Simply remove the spoiler by lifting straight up leaving the T-strips secured to the decklid.

### STEP 5.

Using a 1/8" drill bit, drill thru the T-strip holes and into the decklid. It is not necessary to drill through a double panel on this particular application because we can utilize the factory openings on the underside.

### STEP 6.

Remove T-strips and using a 5/16" drill bit, drill thru the 1/8" hole in step 5. If a "double panel" does exist, use a 3/4" drill bit to drill thru the "inner panel". This allows the ratchet or nutdriver to secure the screw tightly against the upper panel.

### STEP 7.

After deburring all holes, apply small amounts of primer which will help prevent rusting of the freshly drilled metal.

### STEP 8.

Pull back pedestal gaskets exposing mounting tape and place spoiler on decklid and using supplied screws secure to the vehicle using a ratchet or nutdriver. Be sure to feed the LED light wire through the pre-determined hole. Apply small amounts of silicone based caulk over mounting screws as this will help prevent leaking, rusting, or loosening of screws. *TIP: Gasket material is extremely sticky once exposed, so we found that spraying it with water or glass cleaner will allow you to reposition spoiler as needed.*

### STEP 9.

When installing a LED brake light it is recommended to splice into the 3rd brake light in the vehicle and attach spoiler wires using electrical tape. Step on the brake light to ensure proper wiring, simply switch the two connections if spoiler does not light.

### STEP 10.

Finish your install by vacuuming any debris or metal shavings and then reinstall any panels, mats or other items that may have removed earlier in installation.

## Bolt-On Application Step-By-Step



### KIT INCLUDES

Rear Spoiler  
Mounting Gasket  
Plastic Locator T-Strips  
Mounting Screws  
LED Brake Light \*  
LED Mounting Screws \*  
Instructions

\* when applicable

### TOOLS REQUIRED

Drill  
Drill Bits (1/8", 5/16" and 3/4")  
Panel Puller \*  
3/8" Ratchet or Nutdriver  
Silicone Based Caulk  
Measure Tape  
Tape (Electrical, Masking)

### PAINT INSTRUCTIONS

1. Inspect spoiler for imperfections. If filling is required use a catalyzed body filler.  
2. If a catalyzed body-filler is used, be sure to prime over spot.  
3. Sand spoiler with 400 grit, or finer, wets sand paper until smooth.  
4. Apply basecoat / clearcoat finish of your choice.  
*Note: This spoiler has been coated with a catalyzed primer/sealer. Unless additional filling has been done, no primer is required.*