



2007 Infiniti G37 Rear Spoiler Installation Instructions

CDDR-1098 – With Camera Notch and NO 3rd Brake Light

CDDR-1099 – NO Camera Notch and NO 3rd Brake Light

Please note: This is an aftermarket rear spoiler. The actual Infiniti part has the rear camera built into the rear spoiler itself. We had to make slight variations to accommodate vehicles with a rear camera but without a rear spoiler option, as the camera is in the chrome piece itself, thus creating our interpretation of a notch-out to allow the camera to function.

The above listed parts DO NOT have the 3rd Brake light option and installs over the existing chrome piece on the decklid.

STEP 1. After opening and inspecting your rear spoiler you can begin the installation. Notice that the 3M mounting tape comes pre-installed from the factory, which will shave some time off the installation.

STEP 2. Start out by turning over the spoiler and setting it on a soft surface, to prevent any scratches. Remove the 2 screws and replace with the plastic locator T-strips into the 2 mounting holes on spoiler. TIP: A small piece of masking tape is helpful in holding the T-strips in position.

STEP 3. Both of these parts are manufactured to go over the existing chrome on decklid. Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a "perfect" alignment.

STEP 4. Using masking tape, secure locator T-strips to the decklid of the vehicle. Simply remove the spoiler by lifting straight up leaving the T-strips secured to the decklid.

STEP 5. Using a 1/8" drill bit, drill thru the T-strip holes and into the decklid.

STEP 6. Remove T-strips and using a 5/16" drill bit, drill thru the 1/8" hole in step 5. If a "double panel" does exist, use a 3/4" drill bit to drill thru the "inner panel". This allows the ratchet or nutdriver to secure the screw tightly against the upper panel.

STEP 7. After deburring all holes, apply small amounts of primer which will help prevent rusting of the freshly drilled metal.

STEP 8. Pull back 3M tape backing exposing mounting tape and place spoiler on decklid and using supplied screws secure to the vehicle using a ratchet or nutdriver. Apply small amounts of silicone based caulk over mounting screws as this will help prevent leaking, rusting, or loosening of screws. TIP: 3M Tape is extremely sticky once exposed, so we found that spraying it with water or glass cleaner will allow you to reposition spoiler as needed.

STEP 9. If installing on vehicle with camera option, make sure that the notch out does not interfere with the camera area. Check the cockpit of the vehicle to ensure your viewing area is undisturbed.

STEP 10. Finish your install by vacuuming any debris or metal shavings and then reinstall any panels, mats or other items that may have removed earlier in installation.